


DRIFLOWER™



THE ROLLING DRI-RACK™

• ASSEMBLY INSTRUCTIONS •

PARTS INCLUDED

The Rolling Dri-Rack pieces :

METAL BARS

- 2 - 24 - 42" Wheel-Bar (1.5"x1.5" sq.) (A)
- 1 - 78" Cross-Bar w/ sticker (1.5"x1.5" sq.) (B)
- 2 - 76.5" Vertical Posts (1.5"x1.5" sq.) (C)
- 3 - 91" Aluminum Stick (1.5"x .75") (D)
- 1 - 75" Top-Bar (1.5"x .75") (E)

BRACKETS

- 6 - J-Brackets (J)

WHEELS

- 4 - Locking Castors (O)

NUTS & BOLTS

- 6 - 3 3/4" Hex Head Bolts (1/2) (i)
- 2 - 3" Hex Head Bolts (1/2) (¥)
- 12 - 1/2" Hex Nuts (13) (n)
- 20 - 1/2" Washers (w)
- 12 - 2" 10-24 Pan-Head Bolt (Δ)
- 12 - #10-24 Hex Nut (Ø)

RECOMMENDED TOOLS (NOT INCLUDED)

Ratchet Wrench
Sockets 3/4", #10
Pliers / Wrench
Phillips Screwdriver



PREPARE TO BUILD YOUR ROLLING DRI-RACK

Congratulations!

The DriFlower Rolling Dri-Rack is the heart of your HangHarvesting system to streamline and organize your harvest.

MAKE SURE TO READ ALL OF THESE INSTRUCTIONS

After reading the instructions, make sure you have the correct pieces and screws for each assembly (listed on the front page of these instructions).

You will start by building the base-assembly. Then assemble the Vertical Posts. Next, connect the Vertical Posts to the base-assembly. Secure the Top-Bar in place, and lastly, place the Aluminum Sticks in the J-Brackets.

DON'T STRESS - TIGHTEN LESS

When assembling, we recommend **not** fully tightening all nuts and bolts until all pieces are assembled. Simply hand-tighten the connections so there is adjustability when connecting other pieces.

Once the rack is fully assembled, then tighten all connections with the recommended tools.

KEEP YOUR EYE ON THE PRIZE


Keeping a visual check on the center alignment of your rack will make for easy assembly and usage. For example, when attaching the Vertical Posts to the base-assembly,
**** make sure all the pre-drilled holes line up.**

Another important alignment, the Aluminum Stick should be centered for proper weight distribution on the rack.


***** Make sure the J-Bracket stick slots are directly over the Cross-Bar.**

Take your time. This Dri-Rack is about to transform the way you handle your harvest!

BUILD YOUR BASE-ASSEMBLY



Begin by attaching all four castors (O) to the two Wheel-Bars (A). Thread the castor bolt through **both** holes on each end of the Wheel-Bars and fit the castor washer and nut on the top end of the castor bolt (as pictured) tighten by hand.




Attach both Wheel-Bars **above** the center holes of the Cross-Bar using 3 3/4" hex bolts (i), washers (w) and 1/2" hex nuts (n) on each side. Tighten by hand.

Eye on the prize moment

*Make sure to attach the Cross-Bar underneath the Wheel-Bars so that the Cross-Bar is on the same side as the Castor Wheels.


ASSEMBLE VERTICAL POSTS



Attach 3 J-Brackets to each Vertical Post using 2" 10-24 pan-head bolts (Δ) through the holes on the J-Brackets, then through the pre-drilled holes on the Vertical Posts and fasten with the #10-24 Hex Nuts (Ø).

CONNECT VERTICAL POSTS TO BASE-ASSEMBLY

4



*** IMPORTANT NOTE:** VERTICAL POSTS HAVE TWO SETS OF PRE-DRILLED HOLES ON THE BOTTOM OF EACH POST THAT ALIGN WITH THE HOLES OF YOUR BASE-ASSEMBLY.

Eye on the prize moment

****** Make sure to align your Vertical-Posts so that both sets of holes line up with the off-center holes in the Wheel-Bars **and** the holes of the Cross-Bar (sticker side). Correct alignment places the J-Brackets directly over the center of the rack, over the Cross-Bar.

******* Make sure the J-Bracket stick slots are directly over the Cross-Bar.

This centers the J-Bracket slots to hold the Aluminum Stick.


Use the 3 3/4" hex bolts (i), washers (w) and 1/2" hex nuts (n) on each side of the Wheel-Bar directing the bolt thread toward the inside of the rack.

Tighten by hand.

CONNECT VERTICAL POSTS TO CROSS-BAR

5

MAKE SURE STEP 4 HAS BEEN COMPLETED CORRECTLY BEFORE PROCEEDING.



**** IMPORTANT NOTE:** MAKE SURE THE PRE-DRILLED HOLES IN THE VERTICAL POSTS ALIGN WITH THE HOLES IN THE CROSS-BAR OF THE BASE-ASSEMBLY.


******If step 4 of these instructions has been completed correctly, you will be able to easily fasten the Vertical-Posts to the Cross-Bar with 3 3/4" hex bolts (i), washers (w) and 1/2" hex nuts (n) on each side of the Base-Assembly.

Tighten by hand.

CONNECT TOP-BAR TO VERTICAL POSTS

6

USE THE SMALLER BOLTS




Attach the Top-Bar to the Vertical Posts using 3" hex bolts (¥), washers (w) and 1/2" hex nuts (n) on each side.

Eye on the prize moment

******* Make sure to attach the Top-Bar on **the opposite side** of the J-Brackets so that J-Hangers can be placed on Aluminum Sticks without interference.


7



Once all parts have been connected tighten each screw and nut using the appropriate wrenches and drivers.

PLACE ALUMINUM HANGER STICKS

8



Once all connections have been tightened, place your aluminum sticks in the J-Bracket slots so that the sticks are evenly distributed with equal ends on each end.

Bring in your flower and start drying!

For a video of this assembly and to view other videos and instructions, please visit us online at:

<https://driflower.com/support/brochures-and-manuals/>

